



slotted screw holes allow "drop-in installation. nuts left in place Ø

Ø

Ø

Ø





