

# ZTF Mechanical Walkthrough


Matthew Hoff

2013-02-01

# Mechanical Walkthrough

ZTF Technical Meeting

2013-02-01



ZTF Dewar attached to focus hub


# Basic Dimensions

ZTF Technical Meeting

2013-02-01

Weight approx. 105 kg


O-ring length approx. 7,000mm



# Exploded View

ZTF Technical Meeting

2013-02-01



# Window Enclosure



ZTF Technical Meeting

2013-02-01

Aluminum, non-reflective treatment

Filter registers  
to this surface

This flange bolts  
to Dewar



Section view

Enclosure slides over the window and bolts to the Dewar can. Easily attached or removed at any time.




# Window Retainer and Stop

ZTF Technical Meeting

2013-02-01


Delrin window  
retainer

Section view



Held in place with  
standard bolts

Window stop accurately locates the window



Delrin stop held with a  
button head cap screw.  
Qty 8




# Window

ZTF Technical Meeting

2013-02-01

20kg

Fused Silica,  
biconcave




# Faceted Focal Plane Assembly

ZTF Technical Meeting

2013-02-01

12 CCD packages

2 guiders shown, 4 locations are possible







# Exploded view of Focal Plane

ZTF Technical Meeting

2013-02-01

Note the spherical curve formed by the faceted placement of the CCD packages



# Cold Plate


ZTF Technical Meeting

2013-02-01


Aluminum, machined from a  
single piece of plate stock  
11.5kg

40mm thick ⇅


Facet angle



Section view



Front




Back

# CCD Package and Flattener Assembly

ZTF Technical Meeting

2013-02-01






# Flexure

ZTF Technical Meeting

2013-02-01

G-10  
Quantity 4



# Radiation Shield with Doors

ZTF Technical Meeting

2013-02-01


Gold plated sheet copper, polished

The doors seal the Radiation shield after CCD packages are installed.

Doors have slots for flex cables

The doors snap and lock into place using spring wire

Thermal link door not designed yet



# Dewar Can

ZTF Technical Meeting

2013-02-01

Aluminum, machined from plate stock, no welding  
9kg


Double O-ring grooves to cushion window

CCD packages are fully  
accessible with the window  
removed

Extension brackets for  
Flexure attachment  
points

Tapped holes for hoist rings

Section view






# Vacuum Interface Board (VIB)

ZTF Technical Meeting

2013-02-01

The O-ring sealing zone is just inside the bolt hole pattern on both sides of the board

Connectors inside the vacuum



Connectors outside the vacuum


A giant circuit board that crosses the vacuum seal and carries signals from connectors inside the Dewar to connectors outside the Dewar.



Previous VIB's

← KMTNet VIB


↓ Cambridge VIB



# Thermal Link

ZTF Technical Meeting

2013-02-01




# Back Wall


ZTF Technical Meeting

2013-02-01

Stainless steel



Focus hub adapter  
mounting zone






# Back Wall Ports

ZTF Technical Meeting


2013-02-01



# Cross-section Detail

ZTF Technical Meeting

2013-02-01



# Future Work

---

ZTF Technical Meeting

2013-02-01

## VIB redesign

*Rotate inside connectors on the board 90 degrees*

*Reduce hole quantity and hole size in the board*

*Relocate the outside connectors on the board to a single run on the bottom*

Design a 4<sup>th</sup> flexure that is not over determined

Simplify thermal links to 2 flex joints and 2 bolted connections

Front mask (radiation shield) design

Integrate guiders and connectors

Integrate heaters and thermal couples on the cold plate

Integrate window handling parts

Integrate focus hub mounting plate and possible tip – tilt mechanism

Integrate precise distance from window and CCD surfaces to focus hub.



# Assembly Sequence

ZTF Technical Meeting

2013-02-01

