

Fibers for Big Boss

Optical Performance

- Throughput

- Fiber

- End finishing

- Focal ratio degradation

Opto-Mechanical

- Fiber construction

- Fiber input assembly (actuator)

- Fiber output end slit assembly (spectrograph slit)

Fiber Run & Support

- Focal Plane

- Telescope

- Spectrograph

Optical Performance

Bulk Fiber Throughput:

Wavelength dependent attenuation versus length

350 - 1130 nm

high OH silica - good for UV

low OH silica - good for mid-band and NIR

The competitors



Polymicro, NA 0.22

CeramOptec, NA 0.28


Polymicro
attenuation
NA 0.22


High OH FV

Low OH FPB




Polymicro Low OH FBP






CeramOptec
Optran
N.A 0.28




Polymicro

30m




Polymicro

40m



Polymicro

50m




Throughput: End finish AR coating

+ AR ~4% per end

AR direct to fiber ends
(post glue & polish)

AR on cover w/ index matched oil/glue
“fills polishing imperfections”



Throughput: Focal Ratio Degradation (FRD)

$$\underline{f/\# \text{ Out} < f/\# \text{ In}}$$

If spectrograph performs @ $f/\#$ out,
then there is no performance loss.

Effects:

- micro-bending in batch glass draw
- stress
 - . bend radius ($< \sim 250 \times$ fiber dia.)
 - . jacket contact
 - . fiber termination mechanical / thermal

@ low $f/\#$ - scattering \Rightarrow NA limit losses

@ high $f/\#$ - modes are poorly filled, big FRD




Fig. 7 The vertical axis is the absolute transmission into a aperture equivalent to the input f-ratio given on the horizontal axis. Both the FHP320 and FHP100 fibers are shown.

Focal ratio degradation in optical fibers of astronomical interest
 Authors: Ramsey, Lawrence W., 1998 ASPC




Figure 11. Output f -ratio as a function of the input f -ratio for the test fibre. The squares are the values obtained from the experimental results and the solid line corresponds to the results obtained from the model's predictions. The values of the output f -ratio were derived from output beam profiles shown in Fig. 9. The dashed line corresponds to the predictions from the model without any tilt in the function G .

A method for determining the focal ratio degradation of optical fibres for astronomy
 Authors: Carrasco, E.; Parry, I. R.
 Mon. Not. R. Astron. Soc., 271, 1

BOSS Fiber FRD tests

Schlegel


Polymicro FBP fibers
120 micron cores

FRD on fibers delivered
by 3 vendors.

We simply illuminated at
f/5, and took a picture
of the output beam.

Attached are some
aggregate profiles.

**Results are consistent
with just a few percent
of the light being
thrown at larger
angles** than captured by
our throughput tester.



Fiber construction

Core & Cladding:

clad ratio 1.1 (to 1.2 for IR)


[secondary soft cladding for strength]

Coating

hard (e.g polyimide)

vs.

soft & hard coating (epoxy or acrylic)



Prieto, 2000 VIRMOS

A double layer of cladding is then applied. The first one is doped silica, and the second one is pure silica giving robustness to the fiber

External coating an epoxy [or acrylic] double layer coating
The central layer is soft and prevents stress on the fiber, while the outer one is strong and gives robustness to assembly

Low stress design for fiber survival and FRD stability

Ferrule material (TCE match) & design

Glue selection, gap & bonding conditions

End polishing

Jacket termination

Positional Tolerances

Focal plane:

Axial position tolerance.

Angular pointing within FRD

Fiber input & output assembly


Spectrograph feed slit:

Figure radius tolerance

Lateral tolerance vs dispersion

Angular tolerance vs pupil output

Spacing between fibers



Fiber termination:


V-grooves in Si , +/- 1 μm , parallel - Approximate F.P.?

EDM in metal or ceramic machining, +/- 5 μm , aimed grooves

Micro-drilled holes

Stacked fibers, etc.

Fiber output assembly - Microlensed ?




- **E. Prieto:**


— “The best case for me should be to have 70 μ m fiber illuminated at F/2.3. Having this, I could use a offner design with the grating on the secondary (see attachment). A solution like this will have high throughput from UV to NIR.”

Micro lens array
along slit face
(but its curved)

Inter-fiber
spacing is limited
by lens size



Fiber run & support



30 to 50 (!) meters


Focal plane to El. mount
balanced

Elevation mount rotation scheme
limited clearance !!!

Elevation mount to Polar bearing

Polar mount rotation scheme

Polar mount to spectrograph



JE, UCB 16 Feb 10

Main Fiber Issues

Fiber type selection

Size & mass of bundle groups (power wires ?)

Fiber routing on telescope

Spectrograph slit tolerance demands

Fiber slit assembly design

Fiber input ferrule design