

Readout Electronics Concept

- •CDS Correlated Double Samples is used for readout of the CCDs to achieve the required readout noise. Programmable gain receiver, dual-ramp architecture, and ADC buffer. HgCdTe compatible.
- •ADC 16-bit, 100 kHz equivalent conversion rate per CCD (could be a single muxed 400 kHz unit).
- •Sequencer Clock pattern generator supporting modes of operation: erase, expose, readout, idle.
- •Clock drivers Programmable amplitude and rise/fall times. Supports 4-corner or 2-corner readout.
- •Bias and power generation Provide switched, programmable large voltages for CCD and local power.
- •Temperature monitoring Local and remote.
- •DAQ and instrument control interface Path to data buffer memory, master timing, and configuration and control.

